

639 Manhattan Blvd. Harvey, LA 70058 USA TEL: (504) 362-8124 FAX: (504) 362-3600 www.aquaairind.com

EMAIL sales@aquaairind.com

BR67 Breaker





	G •8• 4•		
Specifications			
ITEM	U.S.A.	METRIC	
Input Flow Range	7 – 9 gpm	26 – 34 lpm	
Input Pressure	1500 – 2000 psi	105 – 140 bar	
Max. Back Pressure	250 psi	17 bar	
Optimum Flow	8 gpm	30 lpm	
BR67			
Steel Capacity	6 (15.2 cm) x 1-1/8 Hex 8	& 6 (15.2 cm) x 1-1/4 in. Hex	
Weight	67 lbs.	30 kg	
Length	27 in.	68 cm	
Width (at handles)	16 in.	41 cm	
BR67S			
Steel Capacity	6 (15.2 cm) x 1-1/8 Hex 8	& 6 (15.2 cm) x 1-1/4 in. Hex	
Weight	75 lbs.	34 kg	
Length	29 in.	73 cm	
Width (at handles)	18 in.	46 cm	
Porting	8 SAE O-Ring		
Connector	3/8 in. Male Pipe Hose End		

Features and Benefits

Stanley's line of handheld breakers is the largest in the world, with a wide selection of models suited to virtually any application. The **BR67** and **BR67S** are medium-duty tools for work in the 70-90 pound class. They are highly productive in utility construction, street maintenance, repair of water and gas mains, and general contracting jobs. Available in both a T-Handle and Anti-Vibration Handle Model. Spring-Dampened, Anti-Vibration Handles (BR67S) reduce operator fatigue, allowing the breaker to float in the user's hands. Built in handle stops allow operator to apply full body weight in tough applications. Easi-RideTM foot, offered on the **BR67**, absorbs and controls tool-bit bounce, greatly reducing operator fatigue. Feathering On/Off Valve controls blow speed, making startup and initial tool placement easy. Diaphragm Accumulator provides trouble-free operation with system back pressures up to 250 psi (17 bar). Accumulator on **BR67S** can be serviced without disassembling the tool. Both models operate on open-center systems and are available in 1-1/8 or 1-1/4 in. chuck hex sizes.



639 Manhattan Blvd. Harvey, LA 70058 USA TEL: (504) 362-8124 FAX: (504) 362-3600 www.aquaairind.com EMAIL sales@aquaairind.com

BR67 Breaker Cont.

	Accessories		
PART NO.	DESCRIPTION		
1 1/8 in. Hex x 6 in. Shank			
02331	Clay Spade, 5-1/2 in. (14 cm) blade		
02332	Asphalt Cutter, 5 in. (12.7 cm) blade x 11 in. (28 cm) *		
02333	Moil Point, 14 in. (35.6 cm) *		
02334	Chisel, 3 in. (76 mm) blade x 14 in. (35.6 cm) *		
03990	Chisel Point, 14 in. (35.6 cm) *		
04176	Ground Rod Driver, 1 in. (25 mm) rod		
08106	Asphalt Wedge, 12 in. (30.5 cm) *		
08107	Keen Kut, 16 in. (40.6 cm) *		
1 1/4 in. Hex x 6 in. Shank			
02335	Asphalt Cutter, 5 in. (12.7 cm) blade x 11 in. (28 cm) *		
02336	Moil Point, 14 in. (35.6 cm) *		
02337	Chisel, 3 in. (76 mm) blade x 14 in. (35.6 cm) *		
02338	Heavy Duty Chisel, 1 in. (25 mm) x 14 in. (35.6 cm) *		
04367	Ground Rod Driver, 1 in. (25 mm) rod		
04404	Heavy Duty Moil Point, 18 in. (45.7 cm) *		
04405	Clay Spade, 8 in. (20.3 cm) blade		
08118	Brick Wedge		
18119	Asphalt Wedge		
09262	Clay Spade, 5-1/2 in. (14 cm)		
17782	Detachable Shank (requires no. 17783)		
17783	Tamping Pad, 6 in. (15.2 cm) pad (requires no. 17782)		

^{*} Length measured from bottom tip of tool to bottom surface of collar.

Test Equipment		
PART NO.	DESCRIPTION	
02835	Accumulator Tester	
03189	20 gpm (75 lpm) Flow Meter	
04182	Flow and Pressure Tester	
06545	Accumulator Charge Kit	



639 Manhattan Blvd. Harvey, LA 70058 USA TEL: (504) 362-8124 FAX: (504) 362-3600

www.aquaairind.com
EMAIL sales@aquaairind.com

BR67 Breaker Cont.

Model Numbers		
MODEL	DESCRIPTION	
BR67120	BR67 T-Handle Breaker, 1-1/8 in. Hex	
BR67120E	BR67 T-Handle Breaker, 1-1/8 in. Hex, Easi-Ride Foot	
BR67130	BR67 T-Handle Breaker, 1-1/4 in. Hex	
BR67130E	BR67 T-Handle Breaker, 1-1/4 in. Hex, Easi-Ride Foot	
BR67320	BR67 Underwater T-Handle Breaker, 1-1/8 in. Hex	
BR67330	BR67 Underwater T-Handle Breaker, 1-1/4 in. Hex	
BR67125	BR67S Anti-Vibration Handle Breaker, 1-1/8 in. Hex	
BR67135	BR67S Anti-Vibration Handle Breaker, 1-1/4 in. Hex	

Note: All models listed above ship with hose whips.

Service Tools		
PART NO.	DESCRIPTION	
04596	Seal Kit	
04908	Split Ring (Auto Valve Removal)	
04909	Spacer (Flow Sleeve Install)	
04910	Flow Sleeve Removal Tube	
05508	Accumulator Disassembly Tool	
05640	Accumulator Cylinder Puller	

